

MANUFACTURER'S CODES

Setup Codes For Audio Tuners (cont'd)

| | |
|--------------|--|
| Optimus | 1023, 0531, 0670, 0186, 0080, 0738, 0801, 0042, 0181, 0219, 0177, 0440, 0744, 0622 |
| Orient Power | 0744 |
| Panasonic | 1518, 0039, 0309, 0518 |
| Penney | 0195, 0201 |
| Philips | 1089, 1189, 1269, 0189, 1120, 0412, 0642 |
| Philips | 0391 |
| Pioneer | 1023, 0531, 0014, 0150, 0630, 0080, 0289 |
| Polk Audio | 0189 |
| Proscan | 1254 |
| Quasar | 0039 |
| RCA | 1023, 1254, 0531, 0080, 0360, 0054, 1154, 0346, 0530 |
| Radio Shack | 0744 |
| Realistic | 0195, 0181, 0163, 0182 |
| Sansui | 1089, 0189, 0346, 0193 |
| Sanyo | 0801, 0219 |
| Schneider | 0364 |
| Scott | 0322, 0163, 0105, 0390 |
| Sears | 0201 |
| Semivox | 0255 |
| Sharp | 0186, 0117 |
| Sherwood | 0491, 0502, 0062, 0475, 0565, 0066 |
| Sonic | 0281 |
| Sony | 1058, 1158, 1258, 0158, 0474, 0168, 0415 |
| Soundesign | 0670 |
| Sunfire | 1313, 0313, 0314 |
| Sylvania | 0222 |
| Symphonic | 0182 |
| Tandberg | 0204 |
| Teac | 0463, 0163, 0387 |
| Technics | 1308, 1309, 1518, 0039, 0309, 0208, 0518 |
| Techwood | 0281, 0364, 0344 |
| Thorens | 1189 |
| Victor | 0074 |
| Wards | 0158, 0014, 0189, 0080, 0054 |
| Welton | 0344 |
| Yamaha | 0176, 1176, 0186, 0081, 0082 |
| Yorx | 0195 |
| Zenith | 0857, 0281, 0744, 0622 |

Setup Codes For Cable Converters

| | |
|--------------------|--|
| ABC | 0003, 0008, 0014, 0017, 0007, 0011, 0013, 0001 |
| Allegro | 0153, 0315 |
| Americast | 0899 |
| Antronix | 0022, 0207 |
| Archer | 0153, 0797, 0022, 0207 |
| BBT | 0267 |
| Belcor | 0056 |
| Bell & Howell | 0014 |
| Bell South | 0899 |
| Cable Star | 0056 |
| Cabletenna | 0022 |
| Cableview | 0022 |
| Century | 0153 |
| Citizen | 0153, 0315 |
| Colour Voice | 0025, 0031 |
| Comtronics | 0040 |
| Contec | 0019 |
| Digi | 0637 |
| Eastern | 0002 |
| Emerson | 0797 |
| Everquest | 0015, 0040 |
| Focus | 0400 |
| FutureVision | 0649 |
| GC Electronics | 0056, 0207 |
| Garrard | 0153 |
| Gemini | 0015, 0797, 0070 |
| General Instrument | 0476, 0810, 0276, 0011 |
| GoldStar | 0144, 0040 |
| Goodmind | 0797, 0770 |
| Hamlin | 0020, 0259, 0009, 0034, 0273 |
| Hitachi | 0011 |
| Hytex | 0007 |
| Jasco | 0015, 0153, 0315 |
| Jerrold | 0003, 0476, 0012, 0810, 0276, 0014, 0015, 0011, 0024 |
| Linsay | 0440 |
| Magnavox | 0027 |
| Memorex | 0000 |
| Motorola | 1106 |
| Movie Time | 0063, 0156 |
| NSC | 0063, 0156, 0070 |
| Nexus | 0770 |
| Novaplex | 0618 |
| Oak | 0019, 0007 |
| Optimus | 0021 |
| Panasonic | 0000, 0107, 0021 |
| Panther | 0637 |
| Paragon | 0000 |
| Philips | 0305, 0317, 0153, 0025, 0031, 0027, |

| | |
|--------------------|------------------------------------|
| | 0649 |
| Pioneer | 0144, 0877, 0533, 0023, 0533 |
| Popular Mechanics | 0400 |
| Prelude | 0770 |
| Pulsar | 0000 |
| Quasar | 0000 |
| RCA | 0021 |
| RK | 0479 |
| Radio Shack | 0015, 0315, 0797, 0883 |
| Realistic | 0207 |
| Recoton | 0400 |
| Regal | 0020, 0259, 0273 |
| Regency | 0002 |
| Rembrandt | 0011, 0070 |
| Runco | 0000 |
| SL Marx | 0040 |
| Samsung | 0144, 0040 |
| Scientific Atlanta | 0008, 0477, 0877, 0017, 0006 |
| Scam | 0510 |
| Signal | 0015, 0040 |
| Signature | 0011 |
| Sprucer | 0021 |
| StarSight | 0422, 0542 |
| Starcom | 0003, 0015 |
| Stargate | 0015, 0040, 0797, 0770 |
| Starquest | 0015 |
| Sylvania | 0001 |
| TFC | 0310 |
| TV86 | 0063 |
| Tandy | 0258 |
| TeleCaption | 0221 |
| Televiuew | 0040 |
| Texscan | 0001 |
| Timeless | 0418 |
| Tocom | 0012, 0013 |
| Toshiba | 0000 |
| Tusa | 0015 |
| Unika | 0153, 0022, 0207 |
| United Artists | 0007 |
| Universal | 0153, 0191, 0022, 0056, 0207, 0077 |
| Viewstar | 0063, 0258, 0027 |
| Zenith | 0525, 0000, 0899, 0054 |
| Zentek | 0400 |

Setup Codes For DVD Players

| | |
|---------------|------------------------------|
| Aiwa | 0641 |
| Apex | 0672 |
| B & K | 0655, 0662 |
| Denon | 0490, 0634 |
| Fisher | 0670 |
| GE | 0522 |
| Gradiente | 0704 |
| Harman/Kardon | 0582 |
| Hitachi | 0664 |
| Hiteker | 0672 |
| JVC | 0558, 0623 |
| Kenwood | 0534, 0682 |
| Konka | 0711, 0719, 0720, 0721 |
| Magnavox | 0503, 0675 |
| Marantz | 0539 |
| Mitsubishi | 0521 |
| Onkyo | 0503, 0627 |
| Optimus | 0571 |
| Oritron | 0651 |
| Panasonic | 0490, 0677, 0632, 0678, 0679 |
| Philips | 0503, 0539 |
| Pioneer | 0525, 0571, 0632 |
| Princeton | 0674 |
| Proscan | 0522 |
| RCA | 0522, 0571 |
| Samsung | 0573 |
| Sharp | 0630 |

| | |
|---------------|------------|
| Sherwood | 0633 |
| Sony | 0533 |
| Technics | 0490 |
| Techwood | 0692 |
| Theta Digital | 0571 |
| Toshiba | 0503 |
| Yamaha | 0490, 0545 |
| Zenith | 0503, 0591 |

Setup Codes For Home Automation

| | |
|-----------------|------------|
| Comfortex | 0400 |
| Da-Lite | 0780 |
| GE | 0240 |
| Gewa | 0095 |
| LiteTouch | 0084 |
| Louwer Magic | 0401 |
| Lutron | 0597 |
| Luxaflex | 0580 |
| One For All | 0167 |
| Radio Shack | 0240 |
| Sanyo | 0336 |
| Security System | 0167 |
| Grunpy | 0180, 0179 |
| Somfy | 0780 |
| Universal X10 | 0167 |
| X10 | 0167 |

Setup Codes For Satellite Receivers

| | |
|--------------------|------------------------|
| AlphaStar | 0772 |
| Chaparral | 0216, 0053 |
| Echostar | 0775, 1005, 0280 |
| Expressvu | 0775 |
| General Instrument | 0361, 0627, 0869 |
| HTS | 0775 |
| Hitachi | 0819 |
| Homecable | 0238 |
| Hughes Net. Sys. | 0749 |
| IQ | 0210 |
| IQ Prism | 0210 |
| JVC | 0775 |
| Jerrold | 0361, 0627 |
| Magnavox | 0724, 0722, 0725 |
| Memorex | 0724 |
| Next Level | 0869 |
| Panasonic | 0701 |
| Philips | 0724, 0722, 1076, 0725 |
| Primestar | 0361, 0627 |
| RCA | 0566, 0143, 0855, 0392 |
| Radio Shack | 0869 |
| Realistic | 0052 |
| STS | 0210 |
| Samsung | 1109 |
| Sony | 0639 |
| Star Choice | 0869 |
| Toshiba | 0749, 0790, 0082 |
| Uniden | 0724, 0722, 0052, 0238 |
| Zenith | 0856 |

Setup Codes For TVs

| | |
|----------------|------------------------------------|
| A-Mark | 0003 |
| AOC | 0030, 0019, 0185, 0003, 0052, 0137 |
| Abox | 0032 |
| Admiral | 0093, 0463 |
| Adventura | 0046 |
| Aiko | 0092 |
| Akai | 0030 |
| Alaron | 0179, 0183 |
| Ambassador | 0177 |
| America Action | 0180 |
| Ampro | 0751 |
| Anam | 0180, 0068 |
| Anam National | 0055 |
| Archer | 0003 |
| Audiovox | 0451, 0180, 0623, 0092, 0003 |
| Baysonic | 0180 |
| Belcor | 0019 |
| Bell & Howell | 0154, 0016 |
| Bradford | 0180 |
| Brockwood | 0019 |
| Broksonic | 0236, 0463, 0003 |
| CCE | 0217, 0329 |
| CXC | 0180 |
| Candle | 0030, 0056, 0046, 0186 |

| | |
|---------------|--|
| Carnivale | 0030 |
| Carver | 0054 |
| Celebrity | 0000 |
| Cineral | 0451, 0092 |
| Citizen | 0060, 0030, 0056, 0092, 0039, 0280, 0046, 0186 |
| Clairtone | 0185 |
| Concerto | 0056 |
| Contec | 0180, 0185, 0157, 0158 |
| Craig | 0180 |
| Crosley | 0054 |
| Crown | 0180, 0039 |
| Curtis Mathes | 0047, 0747, 1147, 1347, 0054, 0154, 0051, 0451, 0093, 0060, 0030, 0056, 0145, 0016, 0166, 0466, 0039 |

| | |
|-------------|--|
| Daewoo | 0451, 0019, 0623, 0624, 0092, 0039, 0091 |
| Daytron | 0019 |
| Denon | 0145 |
| Dumont | 0017, 0019 |
| Dwin | 0720, 0774 |
| Electrobond | 0000, 0185 |
| Electrohome | 0381, 0389, 0409 |
| Emerson | 0154, 0236, 0463, 0180, 0178, 0179, 0019, 0623, 0624, 0177, 0185, 0282, 0039, 0280, 0038, 0158, 0183, 0182 |

| | |
|------------|--|
| Envision | 0030 |
| Fisher | 0154, 0159 |
| Fujitsu | 0179, 0683 |
| Funai | 0180, 0179, 0171 |
| Futuretech | 0180 |
| GE | 0047, 0747, 1147, 1347, 0051, 0451, 0093, 0178, 0021, 0055, 0282, 0135, 0027, 0279, 0029, 0174 |

| | |
|-----------------|--|
| Gibraltar | 0017, 0030, 0019 |
| GoldStar | 0030, 0178, 0056, 0019, 0032, 0001, 0409, 0106 |
| Gradiente | 0053, 0056, 0392 |
| Grunpy | 0180, 0179 |
| Hallmark | 0178 |
| Harley Davidson | 0179 |
| Harman/Kardon | 0054, 0078 |

| | |
|----------|--|
| Harvard | 0180, 0068 |
| Hitachi | 0056, 0145, 0016, 0151, 0032, 0038, 0279, 0413, 0409 |
| Infinity | 0054 |
| Inteq | 0017 |
| JBL | 0054 |
| JCB | 0000 |
| JVC | 0053, 0182, 0160 |
| Jancil | 0046 |
| KEC | 0180 |
| KMC | 0106 |
| KTV | 0180, 0030, 0185, 0039, 0280, 0217, 0183 |
| Kawasho | 0158 |
| Kaypani | 0052 |
| Kenwood | 0030, 0019 |
| Kloss | 0046, 0024, 0078 |
| Konka | 0707, 0628, 0632, 0638, 0703 |
| LG | 0056 |
| LXI | 0047, 0747, 0054, 0154, 0156, 0178, 0148 |

| | |
|----------|--|
| Logik | 0016 |
| Luxman | 0056 |
| MEI | 0185 |
| MGA | 0150, 0030, 0178, 0019 |
| MTC | 0060, 0030, 0056, 0019, 0185, 0091 |
| Magnavox | 0054, 1254, 0030, 0179, 0187, 0096, 0020, 0186, 0386, 0024, 0028 |

| | |
|------------|--|
| Majestic | 0016, 0015 |
| Marantz | 0054, 0030 |
| Matsushita | 0250 |
| Megatron | 0178, 0145, 0003 |
| Memorex | 0154, 0250, 0463, 0150, 0178, 0179, 0056, 0016, 0106 |

| | |
|------------|--|
| Midland | 0047, 0747, 0017, 0051, 0135, 0039, 0032 |
| Minutz | 0021 |
| Mitsubishi | 0093, 0150, 0178, 0019 |
| Motorola | 0093, 0055 |
| Multitech | 0180, 0217 |
| NAD | 0156, 0178, 0166 |
| NEC | 0030, 0056, 0019, 0497 |
| NTC | 0092 |
| Nikko | 0030, 0178, 0092 |
| Noblex | 0430 |
| Noshi | 0018 |
| Omwa | 0180 |
| Optimus | 0154, 0250, 0166, 0593 |

| | |
|-----------|--|
| Optonica | 0093, 0165 |
| Orion | 0236, 0463, 0179 |
| Panasonic | 0051, 0250, 0055, 0226 |
| Penney | 0047, 0747, 1347, 0156, 0051, 0060, 0030, 0178, 0021, 0056, 0019, 0018, 0135, 0039, 0003, 0027, 0032 |

| | |
|-----------|--|
| Philco | 0054, 0463, 0030, 0145, 0019, 0096, 0020, 0028 |
| Philips | 0054 |
| Pilot | 0030, 0019, 0039 |
| Pioneer | 0166, 0679, 0038 |
| Portland | 0019, 0092, 0039 |
| Princeton | 0717 |
| Prism | 0051 |
| Proscan | 0047, 0747 |
| Proton | 0178, 0466, 0003, 0052 |
| Pulsar | 0201, 0019 |
| Quasar | 0051, 0250, 0055, 0165 |
| RCA | 0047, 0747, 1047, 1147, 1247, 1347, 1447, 0090, 0051, 0093, 0019, 0679, 0180, 0135, 0038, 0029, 0174, 0278 |

| | |
|-------------|--|
| Radio Shack | 0047, 0747, 0154, 0180, 0030, 0178, 0056, 0019, 0165, 0039, 0032, 0409 |
| Realistic | 0154, 0180, 0030, 0178, 0056, 0019, 0165, 0039, 0032 |
| Rhapsody | 0185, 0183 |
| Runco | 0017, 0030, 0603, 0497 |
| SSS | 0180, 0019 |
| Sampo | 0030, 0039, 0052, 0032 |
| Samsung | 0060, 0030, 0178, 0056, 0019, 0032, 0329, 0427, 0482 |

| | |
|----------|--|
| Samsux | 0039 |
| Sansel | 0451 |
| Sansui | 0463 |
| Sanyo | 0154, 0159, 0146, 0484 |
| Scimitsu | 0019 |
| Scotch | 0178 |
| Scott | 0236, 0180, 0178, 0179, 0019 |
| Sears | 0047, 0747, 0054, 0154, 0156, 0178, 0179, 0056, 0171, 0159, 0146, 0015, 0148 |

| | |
|------------|------------------------------------|
| Semivox | 0180 |
| Semp | 0156 |
| Sharp | 0093, 0688, 0165, 0039, 0386, 0157 |
| Shogun | 0019 |
| Signature | 0016 |
| Simpson | 0187, 0186 |
| Sony | 0000, 0080, 0111, 0011 |
| Soundesign | 0180, 0178, 0179, 0186 |
| Spectricon | 0003, 0137 |
| Squareview | 0171 |
| Starlite | 0180 |
| Supre-Macy | 0046 |
| Supreme | 0000 |
| Sylvania | 0054, 0030, 0096, 0020, 0381, 0028 |

| | |
|-------------|--|
| Symphonic | 0171 |
| TMK | 0178, 0056, 0177 |
| TNGI | 0017 |
| Tandy | 0093 |
| Tatung | 0055, 0003 |
| Technics | 0051, 0250 |
| Technol Ace | 0179 |
| Techwood | 0051, 0056, 0003 |
| Teknika | 0054, 0180, 0150, 0060, 0179, 0056, 0019, 0016, 0092, 0039, 0186, 0312 |

| | |
|-----------------|--|
| Telefunken | 0056 |
| Toshiba | 0154, 0156, 0060 |
| Toshiba | 1256 |
| Tosonic | 0185 |
| Totevision | 0039 |
| Trical | 0157 |
| Universal | 0027 |
| Vector Research | 0030 |
| Victor | 0053 |
| Vidikron | 0054, 0242 |
| Vidtech | 0178, 0019 |
| Viking | 0046, 0312 |
| Wards | 0054, 0030, 0178, 0021, 0179, 0056, 0019, 0016, 0165, 0096, 0020, 0080, 0027, 0111, 0028, 0029, 0174 |

| | |
|--------------------|------------------------------|
| White Westinghouse | 0463, 0623, 0624 |
| Yamaha | 0030, 0019 |
| Zenith | 0017, 0463, 0624, 0016, 0092 |
| Zonda | 0003 |

Setup Codes For VCRs

| | |
|----------------|------------------------------|
| Admiral | 0048, 0209 |
| Adventura | 0000 |
| Aiko | 0278 |
| Aiwa | 0037, 0000, 0307 |
| Akai | 0041, 0106, 0061, 0053, 0049 |
| America Action | 0278 |
| American High | 0035 |
| Asha | 0240 |
| Audiovox | 0037 |
| Beaumarck | 0240 |
| Bell & Howell | 0104 |
| Broksonic | 0184, 012 |